

MALE RUN TEE (MRT)

Model Selection Chart

Tube Outer Dia Size : Fractional						
Sr. No.	End Conn 1 Tube OD Size : Inch	End Conn 2 Thread type NPT Male	Central End Conn 3 Tube OD Size : Inch	Model No. For MOC: SS316		
1	1/4"	1/8"	1/4"	SS-MRT-4-2M-4		
2	1/4"	1/4"	1/4"	SS-MRT-4-4M-4		
3	1/4"	3/8"	1/4"	SS-MRT-4-6M-4		
4	1/4"	1/2"	1/4"	SS-MRT-4-8M-4		
5	5/16"	1/4"	5/16"	SS-MRT-5-4M-5		
6	3/8"	1/4"	3/8"	SS-MRT-6-4M-6		
7	3/8"	3/8"	3/8"	SS-MRT-6-6M-6		
8	3/8"	1/2"	3/8"	SS-MRT-6-8M-6		
9	1/2"	1/4"	1/2"	SS-MRT-8-4M-8		
10	1/2"	3/8"	1/2"	SS-MRT-8-6M-8		
11	1/2"	1/2"	1/2"	SS-MRT-8-8M-8		
12	5/8"	1/2"	5/8"	SS-MRT-10-8M-10		
13	3/4"	1/2"	3/4"	SS-MRT-12-8M-12		
14	3/4"	3/4"	3/4"	SS-MRT-12-12M-12		
15	7/8"	1/2"	7/8"	SS-MRT-14-8M-14		
16	7/8"	3/4"	7/8"	SS-MRT-14-12M-14		
17	1"	1/2"	1"	SS-MRT-16-8M-16		
18	1"	3/4"	1"	SS-MRT-16-12M-16		
19	1"	1"	1"	SS-MRT-16-16M-16		

Tube Outer Dia Size : Metric						
Sr. No.	End Conn 1 Tube OD Size : MM	End Conn 2 Thread type NPT Male	Central End Conn 3 Tube OD Size : MM	Model No. For MOC: SS316		
1	6mm	1/8"	6mm	SS-MRT-6mm-2M-6mm		
2	6mm	1/4"	6mm	SS-MRT-6mm-4M-6mm		
3	6mm	3/8"	6mm	SS-MRT-6mm-6M-6mm		
4	6mm	1/2"	6mm	SS-MRT-6mm-8M-6mm		
5	8mm	1/4"	8mm	SS-MRT-8mm-4M-8mm		
6	8mm	1/2"	8mm	SS-MRT-8mm-8M-8mm		
7	10mm	1/4"	10mm	SS-MRT-10mm-4M-10mm		
8	10mm	1/2"	10mm	SS-MRT-10mm-8M-10mm		
9	12mm	1/4"	12mm	SS-MRT-12mm-4M-12mm		
10	12mm	3/8"	12mm	SS-MRT-12mm-6M-12mm		
11	12mm	1/2"	12mm	SS-MRT-12mm-8M-12mm		
12	16mm	1/2"	16mm	SS-MRT-16mm-8M-16mm		
13	18mm	1/2"	18mm	SS-MRT-18mm-8M-18mm		
14	18mm	3/4"	18mm	SS-MRT-18mm-12M-18mm		
15	20mm	1/2"	20mm	SS-MRT-20mm-8M-20mm		
16	20mm	3/4"	20mm	SS-MRT-20mm-12M-20mm		
17	22mm	1/2"	22mm	SS-MRT-22mm-8M-22mm		
18	22mm	3/4"	22mm	SS-MRT-22mm-12M-22mm		



Material Grade Selection Chart				
For following Material Grade (MOC)	Replace First Two Letters of Model No. with following			
SS316L	SSL			
SS304	S4			
SS304L	S4L			
Brass	В			
Alloy 400	ML			
Alloy 600	INC			
Alloy C276	НС			
PTFE	Т			
Carbon Steel	CS			
Note: Above Model Nos. are for NPT Threads. Fd	or BSP Threads Add -B & for BSPT Threads add -BT at end of Model Nos.			

Head Office

"TRUEWAY HOUSE", Plot No. 535/14-15, Sonawala Cross Road No. 2, Nr. M.K. Industrial Estate, Goregaon (East), Mumbai - 400 063, INDIA. Mobile: +91 9321756212, +91 9004146034 | Phone: +91 22 26852241, 26851052.

E-mail

sales@truewayindia.in

Website

www.truewayindia.in

